



Die bestimmungsgemäße Verwendung dieser Werkzeuge ist die Reparatur, Instandhaltung und Wartung von Motoren. Prager & Co KG übernimmt keine Haftung für eine unsachgemäße Verwendung dieser Werkzeuge. Prager & Co KG kann nicht für Schäden an Personen, Gegenständen oder Geräten verantwortlich gemacht werden, die sich bei der Nutzung dieser Werkzeuge ergeben.

Nr. 36610

Motoreinstell-Werkzeug-Satz, VAG

- für 1.2, 1.6 und 2.0L TDI Common-Rail Motoren
- im VW Golf V/VI/Plus, Polo V, Jetta V/VI, Caddy II, Beetle II, Passat B6/B7/CC, Scirocco III, Eos, Touran II, Tiguan, Sharan II, T5 und Amarock
- im Audi A1, A3 (8P), A4 (B8), A5, A6 (C6/C7), TT (8J), Q3 und Q5
- im Skoda Fabia II, Roomster, Praktik, Octavia II, Superb II und Yeti
- im Seat Ibiza (6J), Leon III, Exeo, Altea und Alhambra II
- zum Arretieren der Nockenwellen, Ausgleichswelle und Kurbelwelle
- bei der Demontage und Montage der Nockenwellenräder
- beim Zahnriemenwechsel oder der Motorreparatur

zum Beispiel für Motorcodes:

CAAA, CAAB, CAAC, CAGA, CAGB, CAGC, CAHA, CAHB, CAYA, CAYB, CAYC, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCHA, CEGA, CFFB, CFGC, CFHC, CFHF, CFJA, CFWA, CGLA, CGLB, CGLC, CJAA, CJCA, CJCB

Nr. 36610SP

Motoreinstell-Werkzeug-Satz, VAG

- für 1.2, 1.4, 1.6 und 2.0L TDI Common-Rail Motoren
- auch für die neuen Motoren ab Baujahr 2013
- im VW Golf V/VI/VII/Plus, Polo V, Jetta V/VI, Caddy II, Beetle II, Passat B6/B7/B8/CC, Scirocco III, Eos, Touran II, Tiguan, Sharan II, T5, T6 und Amarock
- im Audi A1, A3 (8P/8V), A4 (B8/8K), A5 (8T/F), A6 (C6/C7/4G), TT (8J), Q3 und Q5
- im Skoda Fabia II/III, Roomster, Praktik, Octavia II/III, Superb II/III, Yeti I/II und Kodiaq
- im Seat Ibiza (6J), Leon III, Exeo, Altea und Alhambra II
- zum Arretieren der Nockenwellen, Ausgleichswelle und Kurbelwelle
- bei der Demontage und Montage der Nockenwellenräder
- beim Zahnriemenwechsel oder der Motorreparatur

zum Beispiel für Motorcodes:

CAAA, CAAB, CAAC, CAGA, CAGB, CAGC, CAHA, CAHB, CAYA, CAYB, CAYC, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCHA, CEGA, CFFB, CFGC, CFHC, CFHF, CFJA, CFWA, CGLA, CGLB, CGLC, CJAA, CJCA, CJCB, CKFB, CKFC, CLHA, CLHB, CNHA, CNHC, CRBC, CRBD, CRFA, CRKA, CRKB, CRLC, CRMB, CRUA, CRVA, CRVC, CSUA, CSUB, CSUD, CSUE, CUA, CUNA, CUPA, CUSA, CUSB, CUTA, CUUA, CUUB, CUVA, CUVC, CUVD, CUWA, CXMA, CXXA, CXXB, CYKA, CZDA, CZJA, DBKA, DCXA, DDA, DEUA, DEUB, DFLA, DFLD, DFMA, DFSA, DFSB



- Motor nicht starten, wenn Werkzeuge noch montiert sind.
- Die Blockierwerkzeuge dürfen nicht beim Lösen oder Festziehen von Kurbelwellen- oder Nockenwellen-Rädern zum Gegenhalten verwendet werden.
- Angegebene Daten erfolgen unter Vorbehalt.
- Diese Werkzeuge nur unter Beachtung aller Sicherheitshinweise, technischen Dokumentationen und Vorgaben des Fahrzeugherstellers verwenden.

Bild Nr.	Bezeichnung	OEM-Vergleichsnummer	36610	36610SP	Artikel Nr.
1	Nockenwellenrad-Abzieher	T10052	✓	✓	6610-06
2	Arretierwerkzeug Spannrolle	T10265	✓	✓	3520-25
3	Spezial-Winkelschraubendreher SW 6 mm	T10264	✓	✓	3520-22
4	Arretierung Kurbelwellen-Zahnriemenrad oval	T10100	✓	✓	3520-06
5	Arretierung Kurbelwellen-Zahnriemenrad	T10050	✓	✓	3520-10
6	Absteckdorn Riemenspanner	T40098	✓	✓	6610-04
7	Nockenwellenrad Gegenhalter	T10051	✓	✓	6610-01
8	Ausgleichswellen-Fixierung	T10255	✓	✓	6612
9	Absteckdorne, 2 Stück	3359	✓	✓	6609-03
10	Kurbelwellen-Arretierung mit Dorn, 2-tlg.	T10490		✓	6609-01
11	Absteckdorne, 2 Stück	T10492		✓	6609-02

Prager & Co KG • Walter-Freitag-Str. 9 • 42899 Remscheid • Germany • Tel.: 02191 / 59259-0 • info@condorwerkzeug.de

**Nr. 36610 /
Nr. 36610SP**

www.condorwerkzeug.com



The intended purpose of these tools is for repairing, servicing and maintaining engines. Prager & Co KG does not accept any liability for incorrect use of any of these products. Prager & Co KG cannot be held responsible for any damage to personnel, property or equipment when using these tools.

Nr. 36610

Timing Tool Set, Audi / VW

- for 1.2, 1.6 and 2.0L TDI Common-Rail engines
- in VW Golf V/VI/Plus, Polo V, Jetta V/VI, Caddy II, Beetle II, Passat B6/B7/CC, Scirocco III, Eos, Touran II, Tiguan, Sharan II, T5 and Amarock
- in Audi A1, A3 (8P), A4 (B8), A5, A6 (C6/C7), TT (8J), Q3 and Q5
- in Skoda Fabia II, Roomster, Praktik, Octavia II, Superb II and Yeti
- in Seat Ibiza (6J), Leon III, Exeo, Altea and Alhambra II
- for locking the camshafts, balancer and crankshaft
- for removal and assembly of the camshaft sprockets
- for timing belt replacement or engine repair

e.g. for engine codes:

CAAA, CAAB, CAAC, CAGA, CAGB, CAGC, CAHA, CAHB, CAYA, CAYB, CAYC, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCHA, CEGA, CFFB, CFGC, CFHC, CFHF, CFJA, CFWA, CGLA, CGLB, CGLC, CJAA, CJCA, CJCB

Nr. 36610SP

Timing Tool Set, Audi / VW

- for 1.2, 1.4, 1.6 and 2.0L TDI Common-Rail engines
- also for the new engines built from 2013 onwards
- in VW Golf V/VI/VII/Plus, Polo V, Jetta V/VI, Caddy II, Beetle II, Passat B6/B7/B8/CC, Scirocco III, Eos, Touran II, Tiguan, Sharan II, T5, T6 and Amarock
- in Audi A1, A3 (8P/8V), A4 (B8/8K), A5 (8T/F), A6 (C6/C7/4G), TT (8J), Q3 and Q5
- in Skoda Fabia II/III, Roomster, Praktik, Octavia II/III, Superb II/III, Yeti I/II and Kodiaq
- in Seat Ibiza (6J), Leon III, Exeo, Altea and Alhambra II
- for locking the camshafts, balancer and crankshaft
- for removal and assembly of the camshaft sprockets
- for timing belt replacement or engine repair

e.g. for engine codes:

CAAA, CAAB, CAAC, CAGA, CAGB, CAGC, CAHA, CAHB, CAYA, CAYB, CAYC, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCHA, CEGA, CFFB, CFGC, CFHC, CFHF, CFJA, CFWA, CGLA, CGLB, CGLC, CJAA, CJCA, CJCB, CKFB, CKFC, CLHA, CLHB, CNHA, CNHC, CRBC, CRBD, CRFA, CRKA, CRKB, CRLC, CRMB, CRUA, CRVA, CRVC, CSUA, CSUB, CSUD, CSUE, CUA, CUNA, CUPA, CUSA, CUSB, CUTA, CUUA, CUUB, CUVA, CUVC, CUVD, CUWA, CXMA, CXXA, CXXB, CYKA, CZDA, CZJA, DBKA, DCXA, DDA, DEUA, DEUB, DFLA, DFLD, DFMA, DFSA, DFSB



- Remove all tools before starting engine.
- Do not use the locking tools as counterholder when loosening or tightening camshaft or crankshaft sprockets.
- No responsibility is taken for the correctness of this data.
- Always observe and follow all safety notes, technical documentations, specifications and instructions of the vehicle manufacturer.

picture no.	description	OEM-comparison number	36610	36610SP	item no.
1	Camshaft Sprocket Puller	T10052	✓	✓	6610-06
2	Tensioner Pulley Locking Tool	T10265	✓	✓	3520-25
3	Specialist Offset Screwdriver, 6 mm	T10264	✓	✓	3520-22
4	Crankshaft Timing Belt Sprocket Locking Tool, oval	T10100	✓	✓	3520-06
5	Crankshaft Timing Belt Sprocket Locking Tool	T10050	✓	✓	3520-10
6	Belt Tensioner Locking Tool	T40098	✓	✓	6610-04
7	Camshaft Sprocket Counter Holder	T10051	✓	✓	6610-01
8	Balance Shaft Locking Tool	T10255	✓	✓	6612
9	Locking Pins, 2 pcs.	3359	✓	✓	6609-03
10	Crankshaft Locking Tool with Pin, 2 pcs.	T10490		✓	6609-01
11	Locking Pins, 2 pcs.	T10492		✓	6609-02

Prager & Co KG • Walter-Freitag-Str. 9 • 42899 Remscheid • Germany • Tel.: 02191 / 59259-0 • info@condorwerkzeug.de

**Nr. 36610 /
Nr. 36610SP**

www.condorwerkzeug.com